



2. Go to System → scroll down → About
3. Under Windows specifications, note:
 - Edition (Home / Pro / Enterprise)
 - Version (e.g., 23H2 / 24H2 / 26H1 etc.)
 - OS build (a longer number)

Fast method: winver (the “tell me the truth” box)

1. Press Win + R
2. Type winver → press Enter
3. A small “About Windows” window shows version + build.

Why this matters (especially for India)

- Windows 11 Home is what most consumer laptops ship with. It's fine – until you want deeper control.
- Windows 11 Pro is where power toggles live (Group Policy tools, BitLocker controls, deeper admin knobs).
- If your Fast Track later says “use Group Policy,” and you're on Home... you'll need the alternative route.

Also, Windows 11's release train keeps rolling. Microsoft's release health pages list versions and builds (for example, new version/build entries like 26H1 with OS build series 28000 are tracked there).

You don't need to memorise this. You just need to know where to look – because in Windows land, the build number is often the difference between “works perfectly” and “why is this missing for me?”

2) Confirm your PC is Windows 11-ready

Windows 11 isn't just a skin on Windows 10. It's an OS that assumes modern security hardware. Two terms matter more than people realise:

- TPM 2.0 (Trusted Platform Module)
- Secure Boot (running on UEFI, not Legacy BIOS)

Microsoft lists these as core system requirements: UEFI + Secure Boot capable + TPM 2.0.

If you bought a laptop in the last ~5 years, there's a good chance you have TPM 2.0 available – sometimes it's just not enabled in firmware.

Step-by-step: Check TPM status in Windows 11

1. Press Win + R
2. Type tpm.msc → Enter
3. Look for:
 - Status: “The TPM is ready for use”

